Host Configuration: BOOTP and DHCP

Introduction

Information needed by a computer that uses TCP/IP protocol suite:

- IP Address
- Subnet mask
- IP address of default router
- IP address of name server

Previous protocols:


- RARP
- BOOTP

BOOTP

The Bootstrap Protocol (BOOTP) is a client/server protocol that *configures a diskless computer or a computer that is booted for the first time*. BOOTP provides the IP address, net mask, the address of a default router, and the address of a name server.


- BOOTP is a static configuration protocol.
- It is a client/server program, boot server can be anywhere in the internet.


Figure 16.1 Client and server on the same network



- BOOTP uses UPD ports 67 and 68
- BOOTP uses a static database

Figure 16.2 Client and server on two different networks





S 1s 67 68 Reply

If broadcast

Figure 16.4 BOOTP packet format

Operation code	Hardware type	Hardware length	Hop count		
Transaction ID					
Number of seconds		Unused			
Client IP address					
Your IP address					
Server IP address					
Gateway IP address					
Client hardware address (16 bytes)					
Server name (64 bytes)					
Boot filename (128 bytes)					
Options					





Padding

Tag

Length

Value (Variable length)

Other options

Tag (255)

End of list

Table 16.1 Options for BOOTP

Description	Tag	Length	Value
Padding	0		
Subnet mask	1	4	Subnet mask
Time offset	2	4	Time of the day
Default routers	3	Variable	IP addresses
Time servers	4	Variable	IP addresses
DNS servers	6	Variable	IP addresses
Print servers	9	Variable	IP addresses
Host name	12	Variable	DNS name
Boot file size	13	2	Integer
Vendor specific	128–254	Variable	Specific information
End of list	255		

DHCP

- The Dynamic Host Configuration Protocol (DHCP) provides static and dynamic address allocation that can be manual or automatic.
- DHCP is successor to BOOTP and is backward compatible.
- DHCP server can be on same network or different network.

Figure 16.6 DHCP packet

Operation code	Hardware type	Hardware length	Hop count		
Transaction ID					
Number of seconds		F Uni	ısed		
Client IP address					
Your IP address					
Server IP address					
Gateway IP address					
Client hardware address (16 bytes)					
Server name (64 bytes)					
Boot file name (128 bytes)					
Options (Variable length)					

Table 16.2 Options for DHCP

Value	Value	
1 DHCPDISCOVER	5 DHCPACK	
2 DHCPOFFER	6 DHCPNACK	
3 DHCPREQUEST	7 DHCPRELEASE	
4 DHCPDECLINE		

Figure 16.7 DHCP transition diagram




Figure 16.8 Exchanging messages

